
TABLE OF CONTENTS

1.0 PURPOSE AND SCOPE	1
1.1 PURPOSE	1
1.2 SCOPE	1
2.0 REFERENCED PUBLICATIONS	1
3.0 DEFINITIONS	1
4.0 PERSONNEL SAFETY	2
5.0 EQUIPMENT	2
5.1 SCANNING METHODS	2
5.2 PULSE SOURCE/TRANSMISSION LINE PULSE (TLP)	4
5.3 PROBES	5
6.0 WAVEFORM AND PULSE GENERATION REQUIREMENTS	5
7.0 TEST SETUP	7
7.1 MANUAL TEST SETUP.....	7
7.2 ROBOTIC TEST SETUP OVERVIEW.....	7
7.3 TEST PARAMETERS.....	8
7.3.1 <i>Scan Area</i>	8
7.3.2 <i>Point Density</i>	8
7.3.3 <i>Field Probe Type</i>	8
7.3.4 <i>Field Probe Orientation</i>	9
7.3.5 <i>Pulse Polarity</i>	9
7.3.6 <i>Pulse Rate and Number of Pulses per Test Point</i>	9
7.4 DUT COMMUNICATION.....	9
7.5 TEST SYSTEM VERIFICATION	9
7.6 TEST STRATEGIES	9
7.7 DATA STORAGE FORMAT.....	12
8.0 RECOMMENDED TEST LEVELS	12
9.0 DISTURBANCE CRITERIA	12
10.0 DOCUMENTATION	13

ANNEXES

Annex A (Informative): Waveform Verification	14
Annex B (Informative): Field Coupling.....	22
Annex C (Informative): Data Visualization.....	25
Annex D (Informative): Bibliography.....	28
Annex E (Informative): Revision History of ANSI/ESD SP14.5.....	29

TABLES

Table 1: General Waveform Parameters.....	7
Table 2: Recommended Test Levels.....	12
Table 3: Geometry Parameters for the Microstrip Trace.....	15
Table 4: Voltage Induced at Each End of a 20-mm Trace	23

FIGURES

Figure 1A: Block Diagram of a Typical Automated Immunity Scanning System.....	4
Figure 1B: Main Components of a Typical Automated Immunity Scanning System.....	4
Figure 2: Principle Representation of the Voltage Induced by the Suggested Transmission Line Pulse Source in the Case of Electric Field Coupling.....	6
Figure 3: Generic Flow Diagram for Scan Test.....	11
Figure 4: Microstrip Trace for Capturing the Induced Voltages.....	15
Figure 5: Rising Edge of the TLP Waveform.....	16
Figure 6: Schematic of the Test Set-up to Capture the Coupled Waveforms at the Trace Ports	16
Figure 7: 5-mm Hx Probe Mounted over the Center of the Trace.....	17
Figure 8: Induced Voltage from the Ez Probe 1 mm above Trace, 1 Kilovolt TLP Charge Voltage	17
Figure 9: Sum and Differential Voltages Caused by the Ez Probe 1 mm above the Trace, 1 Kilovolt TLP Charge Voltage	18
Figure 10: Induced Voltage from the Hx Probe 1 mm above Trace, 1 Kilovolt TLP Charge Voltage.....	19
Figure 11: Induced Voltage from an Hz Probe, $Z_{\text{offset}} = 1$ mm, $X_{\text{offset}} = 4.21$ mm, 1 Kilovolt TLP Charge Voltage.....	19
Figure 12: Induced Voltage from the Ez Probe 5 mm above Trace, 1 Kilovolt TLP Charge Voltage.....	20
Figure 13: Sum and Differential Voltage Induced by the Hz Probe, $Z_{\text{offset}} = 5$ mm, $X_{\text{offset}} = 4.21$ mm, 1 Kilovolt TLP Charge Voltage	20
Figure 14: Illustration of the Electric Field Coupling and its Return Current Flow.....	22
Figure 15: Illustration of the Magnetic Field Caused by a Horizontal Loop Close to a Ground Plane.....	23
Figure 16: Voltage Induced in the Trace when H-probe is offset by 3.5 mm; Monitored at Both Trace Terminations.....	24
Figure 17: Comparison of Two Functionally Identical ICs from Different Vendors	26
Figure 18: Identification of Sensitive Traces Close to a Microprocessor using Immunity Scanning.....	26
Figure 19: Electric Field and Magnetic Field Sensitivity of an LCD.....	27